


# MUSIC clickclock™

## OPERATING INSTRUCTIONS



ginkgo



DESIGN • QUALITY • TIME

It's a block of wood, but make a sound (clap your hands or tap on the top) and it will light up instantly with the time, date and week day. Plus, you can dance or relax to your favourite tune through this block of wood. It lets you stream high-quality audio from your Bluetooth device without the need for cords. The unconventional but genius natural looking speaker is the perfect bedside or desk accessory for people who like their technology a little less conspicuous.


## Main Product Features

- Displays **Time**, **Calendar**, and **Week Day** synchronously
- Sound activated display or permanent display
- 12 and 24 hour formats can be selected (initial mode: 24 hour).
- Alarm clock with clever snooze function
- 3 different alarm settings; 5 or 7 days alarm setting
- 5 meters Bluetooth range
- Compatible with most Bluetooth devices
- Serious high quality sound
- Built-in memory battery.

## Clock Display Introduction



24 hours format PM time display



12 hours format PM time display




24 Hours format setting display



12 Hours format setting display

## Rear View & Button Introduction



**SET:** To access the settings mode.

**UP:** To scrow up when in setting mode. In normal mode to change the 12/24 Hours Format

**DOWN:** To scrow down when in setting mode. In normal mode to access to do the Alarm Setting.

**V/S:** To turn Sound Activation function **ON/OFF**

**MODE:** To turn ON / OFF the Bluetooth function

## Calender/Time Setting

- Press and hold **SET** button for 3 seconds to access the settings mode.
- When **YEAR** is flashing press **UP** or **DOWN** to change the **YEAR**, then press **SET** to go to **MONTH** setting
- When **MONTH** is flashing press **UP** or **DOWN** to change the **MONTH**, then press **SET** to go to **DAY** setting
- When **DAY** is flashing, press **UP** or **DOWN** to change the **DAY**, then press **SET** to go to **TIME** setting
- When **HOUR** is flashing, press **UP** or **Down** to change the **HOUR**; then press **SET** to go to **MINUTE** setting.,
- When **MINUTE** is flashing, press **UP** or **DOWN** to change the **MINUTE**;
- After setting the time, press **SET** to exhibit the setting.

(the week day will automatically change when you are setting the calender)

## 12/24 Hours Format Setting

- Press **UP** to choose 12H format or 24 Hours format
- When in 12H format, there will be a dot on the left top side of time display area if it's PM time

## Alarm Setting

(This clock can be set with 3 different alarms; and alarms can be set with "normal alarm mode" or "week days alarm mode")

- - **AL** Normal alarm mode: the alarm will go off 7 days a week

- **AL** Week day alarm mode: the alarm will go off on week days only

- Press the **DOWN** button to access the alarm setting and the clock will initially be on showing “- AL” , press **UP** and **DOWN** to choose the alarm mode you want to set, and press **SET** to confirm and it will bring you to the first alarm setting page.
- the first alarm is initially turned off with display '- :A1' (to turn alarm **ON** press **UP** button to show '0:00') To turn **OFF** press **DOWN** button.
- To set the first alarm, press **SET** when it's display “0:00”, the hour will flash and then press **UP** and **DOWN** buttons to adjust the hour; press **SET** again, the minute will flash and press **UP** and **DOWN** to adjust minute.
- After adjusting time, press **SET** again. It will go to the second alarm time, initial mode will be '- :A2' (to turn alarm **ON** press **UP** button to show '0:00') To turn **off** press **DOWN** button. Follow the same instructions as above to set the time.
- After pressing **SET**, it will go to the third alarm showing initial mode '- :A3' (to turn alarm **ON** press **UP** button to show '0:00'). To turn **OFF**, press **DOWN** button. Follow the instructions as above. After finishing setting the three alarms, press **SET** it will go back to normal display.

When one of the alarms is turned on, there will be a dot on the right side of minute display area which indicates at least one alarm is turned on.

## Sound Activation Function

The sound sensitive function can be turned off so the time can display continuously without going off. However, to save more energy, it's suggested to have this function turned on.

- To turn sound activation function **ON**, press the '**V/S**' button. When clock displays '**ON:Sd**' , the sound activation function is **ON**. In this mode, the clock display will switch off automatically after 20 seconds, but it will light up instantly when you click your fingers, clap your hands or give a gentle tap on top of it.
- Press the **V/S** button again for the clock to display '- :Sd', means this function is turned **OFF**. In this mode, the clock display will be continuously on without going off.

## Snooze Function Instruction

- The clock comes with a snooze function. The snooze time is 5 minutes each time and it can be snoozed 5 times.
- The snooze function will be turned on automatically when the clock is powered
- When the alarm is sounding, pressing any button will stop the alarm and it will sound again in 5 minutes time.
- Pressing any button twice when the alarm is sounding can turn off the snooze function. The alarm won't sound again until the next day.

## Bluetooth Connecting Instruction

- Press and hold the **MODE** button until you hear a sound. At the same time, the LED lights will keep flashing to indicate the Bluetooth is now turned on.
- After the Bluetooth is turned on, go to your Bluetooth device that you want to play music from. Before trying to connect it to the clock, make sure the Bluetooth on your device is turned on as well.
- When the Bluetooth on your device is turned on, use your device to search for 'GINGKO', which is the Bluetooth device name for the Music Click Clock
- When your device has found 'GINGKO', select to pair it with your device.
- When your device is paired with 'LT-81', your device will show you it's being paired and connected with GINGKO. At the same time,

the Music Click Clock will make a sound when they're successfully connected to each other.

- When connected, you can enjoy your favorite music wirelessly in high quality sound through the music click clock.

You can also connect this music clock to your non-Bluetooth device by 3.5mm AUX wire. Simply plug into the AUX outlet at the back of the clock and plug into your device with the other end.

## Music & Volume Control

- To adjust the music volume, use the volume controls on your Bluetooth device where your music is stored. Volume cannot be adjusted on the clock itself.
- To change the music track, press the PREVIOUS/BACK button or NEXT/FORWARD button on the clock or use the Bluetooth device where your music is stored.

## Important Product Care Notices

- This product is made from wood. Please keep in a dry place and if needed clean with a soft dampened cloth.
- Please only use the adapter supplied with the clock to power this product; If any other adapter is used on this clock, it may damage this clock and we won't be responsible for this.
- Place this item in a safe place and keep away from high heat or wet areas . Heavy knocks or falls may seriously damage this product.

If you still have any other questions about how to use this product, please contact your local distributor or retailers.

Or email us at [support@ging-ko.co.uk](mailto:support@ging-ko.co.uk), we're more than happy to help at any time.

GINGKO ELECTRONICS LTD (UK)

Unit 4, Evans Business Centre, Dunns Close, Nuneaton, Warwickshire, CV11 4NF, United Kingdom

T: +44(0)24 7632 2265 F: +44(0)80 8238 3166 E: [support@ging-ko.co.uk](mailto:support@ging-ko.co.uk)